






<11>

Drawers tilted 45 degrees and pushed in



Insert metal pins to prevent drawers from falling out when pulled out


<12>



Installation is complete


## Door plank of adjustment

The crack of the door is too large




As shown, the screwdriver points to the side, clockwise rotation is to adjust the door panel to the middle

The gap between door panel and side panel is too large



As shown in the figure, loosen the screw pointed by the screwdriver, push the door panel in or out and tighten it, solve the above problems

The door is uneven



As shown in the figure, loosen the screw pointed by the screwdriver, push the lower door panel and hinges up and tighten the screws, push the higher door panel and hinges down and tighten the screws.